

Wall-mounted LiFePO4 Battery Series User Manual 51.2V 100Ah/5.12KWh




Contents

1.Application	4
2.Feature.....	4
3.Advantages	4
4. Standing Specification	5
5. Capacity Expansion Solution	6
6. Folding Inspection.....	7
7. Preparation before Inspection	8
8. Dimension Drawing	9
9. Ports introduce	10
Appendix	11
1. TIGFOX lithium battery RS485/CAN Communication Cable Order (sequence) Instruction	11
2. Dial-up switch settings	11
3. Schematic diagram of parallel connection.....	13
4. How to set the communication for multiple brands of inverters by host computer.....	14
5. CHY Inverter RS485 Communication Setting	15
6. LUXPOWER Inverter CAN Communication Setting (Default protocol)	16
7. Voltronic Inverter RS485 Communication Setting	17
8. DEYE Inverter CAN Communication Setting (Compatible Sunsynk,Default protocol)	19
9. Growatt Inverter RS485 Communication Setting (Default protocol).....	20
10. VICTRON Inverter CAN Communication Setting	21
11. Configuring Communication for Multiple Brands of Inverters on the LCD display	22
12. LED indicator	24
13. LCD states indicate	25
14. Wifi and bluetooth introduce.....	26


User Manual

1.Application

Be specially designed for multiple energy storage application scenarios including household, data center, and commercial building, bank, hospital, school, railway station, airport and telecom, etc.



2.Feature



3.Advantages

- ❶ Long Design Life
- ❷ Multiple Protection
- ❸ Modular Design
- ❹ Dekra Certification
- ❺ Scalable & Flexible
- ❻ Easy Maintenance

4. Standing Specification

No.	Items	Specification
1	Product Name	LiFePO4 Battery
2	Module Model	ARM5120
3	Battery Type	LFP 16S
4	Nominal Capacity	5.12KWh
5	Usable Capacity	4.86KWh (95% DOD)
6	Nominal Voltage	51.2V
7	Working Voltage	43.2 ~57.6Vdc
8	Charging Voltage	57.6V
9	Max. Charge Current	100A
10	Max. Discharge Current	100A
11	Communication Port	RS485, CAN, COM
12	Storage Temperature	-10℃~35℃ (Recommended)
13	Storage Humidity	≤85% (RH)
14	Working Temperature	Charging: 0℃ ~ 55℃ Discharging: -20℃ ~ 60℃
15	Working Humidity	≤95% (RH) No Condensation
16	Working Altitude	≤2000m
17	Ingress Protection	IP54
18	Protective Class	1
19	Weight	48kg
20	Dimension	608*395*185.5mm
21	Shelf life	5 Years (25℃)
22	Cycle life	>6000 (25℃) , 60% EOL
23	Scalability	Module: Max. 16 in parallel (Capacity 81.92kWh)
24	Certification	CE, IEC62619, UN38.3 (upcoming)



5. Capacity Expansion Solution



Product Name	High Capacity Expandable Battery System			
Product Model	ARM5120-2P	ARM5120-3P	ARM5120-4P	ARM5120-5P
Normal Capacity (kWh)	10.24	15.36	20.48	25.6
Normal Voltage (V)	51.2	51.2	51.2	51.2
Working Voltage(V)	43.2~57.6Vdc	43.2~57.6Vdc	43.2~57.6Vdc	43.2~57.6Vdc
Charging Voltage(V)	57.6	57.6	57.6	57.6
Max. Charge Current (A)	200	300	400	500
Max. Discharge Current (A)	200	300	400	500
Scalability	Max. 16 in parallel	Max. 16 in parallel	Max. 16 in parallel	Max. 16 in parallel

6. Folding Inspection

Please check the product before installation. Make sure nothing in the packaging is damaged or missing. You should receive the following items in the package:

No.	picture	Category	Quantities
1		Standing LiFePO4 Battery	1
2		User's Manual (Please keep it for future reference)	1
3		Power cable(optional selection , one unit two cables)	1
4		Communication cable(optional selection)	1
5		warranty card	1
6		Mounting frame	2
7		Expansion Screws	6

7. Preparation before Inspection

Before choosing an installation location, consider the following:

7.1 Do not install this product on surfaces of flammable building materials.

7.2 Mounted on the surface of a solid material.


7.3 Please install this energy storage battery at eye level for a more intuitive view of the the LCD.

7.4 For heat dissipation, ensure that the distance is 20cm from both sides and 50cm from the bottom of the unit.



7.5 The ambient temperature of the installation location should be between 0~45 degrees Celsius to ensure optimal operation.

8. Dimension Drawing

NOTE: The following picture is only a schematic diagram of the equipment. If the actual chassis does not conform to the schematic due to a structural upgrade, it is subject to prior notice.



9. Ports introduce




1. LCD
2. Function buttons
3. On/Off button
4. Reset and multi-function button
5. BCD code(refer to Appendix 2.3)
6. DRY CONTACT port
7. Inverter RS485 communication port
8. Inverter Can communication port
9. Computer communication port
10. Battery parallel RS485 ports
11. Battery Positive
12. Battery Negative
13. On/Off indicate LED

Appendix

Communication Setting With Multiple Brands' Inverters

1. TIGFOX lithium battery RS485/CAN Communication Cable Order (sequence) Instruction

as below:




PIN Number	RS485 PORT		PIN Number	CAN Port
Pin1	RS485-B		Pin1	NC
Pin2	RS485-A		Pin2	NC
Pin3	GND		Pin3	GND
Pin4	NC		Pin4	CANH
Pin5	NC		Pin5	CANL
Pin6	GND		Pin6	GND
Pin7	RS485-A		Pin7	NC
Pin8	RS485-B		Pin8	NC

2. Dial-up switch settings when PACK is used in parallel

2.1 Different PACK can be distinguished by setting the dialing switch on BMS to avoid setting the same address. The definition of BMS dial switch refers to the following table;

2.2 RS485 performing multi-machine parallel communication operation, it is necessary to configure the DIP address of each PACK first. The dialing code adopts BCD code format, the




definition of address 1(master) is

,address 2 is



Dial switch:




2.3 BCD CODE:

Address	Codes the switch position			
	#1	#2	#3	#4
1 master	ON	OFF	OFF	OFF
2 slave	OFF	ON	OFF	OFF
3 slave	ON	ON	OFF	OFF
4 slave	OFF	OFF	ON	OFF
5 slave	ON	OFF	ON	OFF
6 slave	OFF	ON	ON	OFF
7 slave	ON	ON	ON	OFF
8 slave	OFF	OFF	OFF	ON
9 slave	ON	OFF	OFF	ON
10 slave	OFF	ON	OFF	ON
11 slave	ON	ON	OFF	ON
12 slave	OFF	OFF	ON	ON
13 slave	ON	OFF	ON	ON
14 slave	OFF	ON	ON	ON
15 slave	ON	ON	ON	ON

User Manual

3. Schematic diagram of parallel connection

3.1 4 batteries, connect the positive power line of each battery with the positive power line, and the negative power line with the negative power line, as bellow:



4. How to set the communication for multiple brands of inverters by host computer


4.1 Factory default setting of inverter communicate, RS485 is Growatt, CAN is DEYE, SUNSYNK,LUXPOWER. If need switch to other protocol, the COM crystal head of the communication cable is inserted into the battery communication port, the USB end is inserted into the computer;

4.2 Open the BMS tool:



4.3 Select the corresponding inverter protocol from BMS Tool, click setting(设置),then restart the BMS ON/OFF , the inverter protocol will be set successful;

4.4 RS485 protocol and CAN protocol as below:




4.5 Remark of inverter protocol code:


Inverter protocol code remark

RS485 Protocol		CAN Protocol	
Protocol code	Inverter brand	Protocol code	Inverter brand
CHY	ChuangHuiYuan 创汇原	PYLON TECH	PYLON TECH 派能
GROWATT	GROWAT 古瑞瓦特	DEYE	DEYE (SUNSYNK) 德业
VoltronicPower	VoltronicPower 日月元	SOROTEC	SORO Power 索瑞德
SRNE	SRNE 硕日	MEGAREVO	MEGAREVO 迈格瑞能
SAKO	SAKO 三科	GOODWE	GOODWE 固得威
Sumry	Sumry 三瑞	SOFAR	SOFAR 首航
XinDun	XinDun 欣顿	MUST PV1800F	MUST 美克
VICTRON	Victron 维克托	LUXPOWER	Luxpower 鹏程
		VICTRON	Victron 维克托
		SOLIS	Solis 锦浪

5. CHY Inverter RS485 Communication Setting



Dual RJ45 Port(RS485 & CAN):



Process of installation:

Step 1. Use the RS485 cable to connect inverter and lithium battery .


Step 2. Replace the battery BMS protocol to “CHY” by BMS tool and host computer.(Please refer to **page 14,point 4.2**)

Step 3. Turn on the switch of battery , power output ready .


Step 4. Turn on the inverter (**Warning: Turn on the battery first and then the inverter**), and set the program 05 as “LIB” on the LCD, then restart the inverter.

Step 5. Press the ESC button continuously 5 seconds and you can view the BMS communication data.

6. LUXPOWER Inverter CAN Communication Setting (Default protocol)



Dual RJ45 Port(RS485 & CAN):



Process of installation:

Step 1. Use the CAN cable to connect inverter and lithium battery .


Step 2. Replace the battery BMS protocol to “LUXPOEWR” by BMS tool and host computer.(Please refer to **page 14,point 4.2**)

Step 3. Turn on the switch of battery , power output ready .


Step 4. Turn on the inverter (**Warning: Turn on the battery first and then the inverter**)

Step 5. To connect battery BMS, need to set the battery types as “Li-ion” in Program 03. After set“Li-ion”in Program 03, then choose battery brand to “2 Pylon Battery”.

7. Voltronic Inverter RS485 Communication Setting



Dual RJ45 Port(RS485 & CAN):



Process of installation:

Step 1. Use the RS485 cable to connect inverter and lithium battery .Please choose the RS485 inverter

Step 2. Replace the battery BMS protocol to “VoltronicPower” by BMS tool and host computer.(Please refer to **page 14,point 4.2**)

Step 3. Press the button to start lithium battery , power output ready .


Step 4. Turn on the inverter (**Warning: Turn on the battery first and then the inverter**).

Step 5. To connect battery BMS, need to set the battery type:LiB-protocol. After selected,Maximum charging


current, Bulk charging voltage (C.V voltage), Floating charging voltage and Low DC cut off voltage setting

will be automatically set up, no need for further setting.

8. DEYE Inverter CAN Communication Setting (Compatible Sunsynk,Default protocol)




Dual RJ45 Port(RS485 & CAN):




Process of installation:

- Step 1. Use the CAN cable to connect inverter and lithium battery .
 - Step 2. Press the button to start lithium battery , power output ready . Replace the battery BMS protocol to “DEYE” by BMS tool and host computer.(Please refer to **page 14,point 4.2**)
 - Step 3. Turn on the inverter (**Warning: Turn on the battery first and then the inverter**).
 - Step 4. Be sure to select inverter work model type as “Lithium Model: 00” on the inverter screen. As below picture.
- If communication between the inverter and battery is successful, the inverter screen will show the battery system real-time status.


PS:



9. Growatt Inverter RS485 Communication Setting (Default protocol)



Dual RJ45 Port(RS485 & CAN):



Process of installation:

Step 1. Use the RS485 cable to connect inverter and lithium battery .


Step 2. Replace the battery BMS protocol to “GROWATT” by BMS tool and host computer.(Please refer to **page 14,point 4.2**)

Step 3. Turn on the switch of battery , power output ready .


Step 4. Turn on the inverter (**Warning: Turn on the battery first and then the inverter**);

Step 5. Set the program 05 as “LI” on the LCD. After set “LI” in Program 05, it will switch to Program 36 to choose communication protocol, choose RS485 communication protocol L01~L50.

10. VICTRON Inverter CAN Communication Setting



Dual RJ45 Port(RS485 & CAN):



Process of installation:

Step 1. Use the CAN cable to connect inverter and lithium battery .


Step 2. Press the button to start lithium battery , power output ready . Replace the battery BMS protocol to “VICTRON” by BMS tool and host computer.(Please refer to **page 14,point 4.2**)

Step 3. Turn on the inverter (**Warning: Turn on the battery first and then the inverter**).

Step 4. The inverter setting refer to the user manual of Victron, this setting is available in the Settings -> DVCC menu on the GX device.

11. Configuring Communication for Multiple Brands of Inverters on the LCD display

11.1 The factory default setting for inverter communication is RS485 for Growatt and CAN for DEYE, SUNSYNK, and LUXPOWER. To switch to another protocol, select the 'Sys Setting' option by pressing the 'DOWN' button and then press the 'ENTER' button on the battery LCD display to enter. As shown in the figure below:



11.2 Enter from Sys Setting item, When on the following interface, select the corresponding inverter protocol for RS485 terminals from the 'LCDRS485' field and for CAN terminals from the 'LCDCAN' field. Click 'ENTER', then confirm the inverter protocol selection by pressing the 'ENTER' button.



11.3 When you press the ENTER button, you will enter the LCD RS485 setting, as shown below:



11.4 For instance, if you select "--Voltronic 3", press the Enter button, then press the ESC button. After three seconds, LCDRS485 and BMSRS485 will display the same number 3. This indicates that the setting change was successful, as shown below:



11.5 The method of setting LCDCAN is same as LCDRS485.

User Manual
12. LED indicator

状态 State		充电 Charge						放电 Discharge					
容量指示灯 Capacity indicator light		L1	L2	L3	L4	L5	L6	L1	L2	L3	L4	L5	L6
电量 SOC(%)	0~16.6%	灭 Off	灭 Off	灭 Off	灭 Off	灭 Off	闪2 Flash2	灭 Off	常亮 Always on				
	16.6~33.2%	灭 Off	灭 Off	灭 Off	灭 Off	闪2 Flash2	常亮 Always on	灭 Off	灭 Off	灭 Off	灭 Off	常亮 Always on	常亮 Always on
	33.2~49.8%	灭 Off	灭 Off	灭 Off	闪2 Flash2	常亮 Always on	常亮 Always on	灭 Off	灭 Off	灭 Off	常亮 Always on	常亮 Always on	常亮 Always on
	49.8~66.4%	灭 Off	灭 Off	闪2 Flash2	常亮 Always on	常亮 Always on	常亮 Always on	灭 Off	灭 Off	常亮 Always on	常亮 Always on	常亮 Always on	常亮 Always on
	66.4~83.0%	灭 Off	闪2 Flash2	常亮 Always on	常亮 Always on	常亮 Always on	常亮 Always on	灭 Off	常亮 Always on				
	83.0~100%	闪2 Flash2	常亮 Always on										

状态 State	正常/告警/保护 Normal/Alarm/Protection	ON/OFF	RUN	ALM	电量指示 SOC Indicator						
		●	●	●	●6	●5	●4	●3	●2	●1	
关机 Turn Off	休眠 Sleep	灭 OFF	灭 OFF	灭 OFF	灭 OFF	灭 OFF	灭 OFF	灭 OFF	灭 OFF	灭 OFF	灭 OFF
充电 Charge	正常 Normal	常亮 Always On	闪1 Flash1	灭 OFF	依据电量指示(电量指示最高 LED 闪1) According to the power indicator (the maximum power indicator LED flashes 1 time)						
	充电过流 Over charge Current	常亮 Always On	常亮 Always On	闪2 Flash2	常亮 Always On	常亮 Always On	灭 OFF	灭 OFF	灭 OFF	常亮 Always On	
	充电低温 Low charge temp.	常亮 Always On	常亮 Always On	闪2 Flash2	灭 OFF	常亮 Always On	常亮 Always On	灭 OFF	灭 OFF	常亮 Always On	
	充电高温 High charge temp.	常亮 Always On	常亮 Always On	闪2 Flash2	常亮 Always On	灭 OFF	灭 OFF	常亮 Always On	灭 OFF	常亮 Always On	
	芯片低温 Chip low temp.	常亮 Always On	常亮 Always On	闪2 Flash2	灭 OFF	灭 OFF	灭 OFF	常亮 Always On	灭 OFF	常亮 Always On	
	单体过压锁定 Single overpressure lock	常亮 Always On	常亮 Always On	闪2 Flash2	常亮 Always On	常亮 Always On	常亮 Always On	常亮 Always On	灭 OFF	常亮 Always On	

User Manual

状态 State	正常/告警/保护 Normal/Alarm/Protection	ON/OFF	RUN	ALM	电量指示 SOC Indicator					
		●	●	●	●6	●5	●4	●3	●2	●1
放电 Discharge	正常 Normal	常亮 Always On	常亮 Always On	灭	依据电量指示 According to the power indicator					
	放电过流 Discharge over current	常亮 Always On	常亮 Always On	闪2 Flash2	灭 OFF	灭 OFF	常亮 Always On	灭 OFF	灭 OFF	常亮 Always On
	放电短路 Discharge short circuit	常亮 Always On	常亮 Always On	闪2 Flash2	常亮 Always On	灭 OFF	常亮 Always On	灭 OFF	灭 OFF	常亮 Always On
	放电低温 Discharge low temp.	常亮 Always On	常亮 Always On	闪2 Flash2	常亮 Always On	常亮 Always On	常亮 Always On	灭 OFF	灭 OFF	常亮 Always On
	放电高温 Discharge high temp.	常亮 Always On	常亮 Always On	闪2 Flash2	灭 OFF	常亮 Always On	灭	常亮 Always On	灭 OFF	常亮 Always On
	芯片高温 Chip high temp.	常亮 Always On	常亮 Always On	闪2 Flash2	常亮 Always On	常亮 Always On	灭	常亮 Always On	灭 OFF	常亮 Always On
	MOS高温 MOS high temp.	常亮 Always On	常亮 Always On	闪2 Flash2	灭 OFF	灭 OFF	常亮 Always On	常亮 Always On	灭 OFF	常亮 Always On
	AFE失效 AFE Failure	常亮 Always On	常亮 Always On	闪2 Flash2	常亮 Always On	灭 OFF	常亮 Always On	常亮 Always On	灭 OFF	常亮 Always On
	放电过流锁定 Discharge overcurrent lock	常亮 Always On	常亮 Always On	闪2 Flash2	灭 OFF	灭 OFF	灭 OFF	灭 OFF	常亮 Always On	常亮 Always On
	短路锁定 Short circuit lock	常亮 Always On	常亮 Always On	闪2 Flash2	常亮 Always On	灭 OFF	灭 OFF	灭 OFF	常亮 Always On	常亮 Always On
	单体欠压 Single cell undervoltage	常亮 Always On	常亮 Always On	灭 OFF	灭 OFF	灭 OFF	灭 OFF	灭 OFF	灭 OFF	灭 OFF

13. LCD states indicate

```

"====Welcome===="
" SOC: 100% "
" STATE: OK "
"====Home page===="

```

- STATE : OK(BMS normal)
- SigOverVoltage(cell over voltage)
- SigUnderVoltage(cell below voltage)
- DSG Over Current(discharge current over the spec)
- CHG Over Temp(Charge current over the spec)
- CHG Under Temp(charge temperature below spec)
- DSG Over Temp(discharge over temperature)
- ShortCircuit (battery output short!)

User Manual**14. WIFI and Bluetooth introduce**

14.1 How to download APP

Method 1: Scan the QR code to enter the download



CHY POWER(iOS)



CHY POWER(Android)

Method 2: A: Apple users enter the App Store and search for 'CHY POWER';


B: Android users, scan the QR code above directly

14.2 How to use the APP

14.21 Login and Registration Page

A: Enter account and password to log in

B: Register a new account page



14.22 Bluetooth network configuration settings

A: Click on Bluetooth configuration network to enter and search for Bluetooth


B: Requires GPS and Bluetooth permissions

C: After selecting the corresponding Bluetooth name, get the surrounding WI-FI network information

D: Select WI-FI network information and enter WI-FI password

E: Network configuration completed

User Manual





14.23 Device binding list page

A: Click on 'adding device' to bind a new WiFi module

B: You can manually enter the PN code or click the scan icon on the right to scan the specified QR code to identify the PN code

C: Add binding completed



14.24 WI-FI View Device Information

A: The header title bar can slide left and right, representing: status information, battery information, calibration parameters, threshold parameters, and tool section

B: The display area below is for quick AT commands and log display

C: You can also set the inverter protocol and update BMS software according to the App;

User Manual

8:53 m 0.13 KB/s 93%

00000136

State info Parallel battery Calibration Threshold

Voltage(mV)

CELL 01	3320	CELL 02	3320
CELL 03	3320	CELL 04	3321
CELL 05	3321	CELL 06	3320
CELL 07	3321	CELL 08	3322
CELL 09	3321	CELL 10	3322
CELL 11	3321	CELL 12	3321
CELL 13	3322	CELL 14	3322
CELL 15	3322	CELL 16	3321

NTC(°C)

AFE	19	MOS	16
CELL1	16	CELL2	16
CELL3	16	CELL4	16
CELL5		CELL6	

Handshake Send AT

Clear LOG Auto Scroll 53:42.214 Version:0.01

08:53:28: **Handshake**

8:55 ... 0.11 KB/s 93%

00000136

State info Parallel battery Calibration Threshold

Inverter protocol

Settings Query

CAN 0.N/A

485 0.N/A

	Time	Voltage(V)	DSG	CHG	PI
01	55:14	53.170	Open	Open	C
02					
03					
04					
05					
06					
07					
08					
09					
10					
11					
12					

Handshake Send AT

Clear LOG Auto Scroll 55:14.169 Version:0.01

08:53:28: **Handshake**

8:55 ... 0.68 KB/s 93%

00000136

State info Parallel battery Calibration Threshold

Read calibration value

CELL Interconnect Resistances(mΩ)

CELL 01	0	CELL 02	0
CELL 03	0	CELL 04	0
CELL 05	0	CELL 06	0
CELL 07	0	CELL 08	0
CELL 09	0	CELL 10	0
CELL 11	0	CELL 12	0
CELL 13	0	CELL 14	0
CELL 15	0	CELL 16	0

Other(mV)

Pack Gain 34082

TOS Gain 34086

LD Gain 34709

Handshake Send AT

Clear LOG Auto Scroll 55:29.740 Version:0.01

08:53:28: **Handshake**

08:55:22: **Data communication failure**

08:55:28: **Read Calibration Success**

08:55:29: **Read Calibration Success**

User Manual

8:55 ... 0.31 KB/s 93%

< 0000136 Wi-Fi

Parallel battery Calibration **Threshold** Tool

Read Write

> Settings

> Power

∨ Protections

	Threshold	Delay	Recovery
			Hysteresis
CUV	2530.0 mV	495.0 mS	404.8 mV
COV	3744.4 mV	495.0 mS	303.6 mV
OTC	55 °C	3 S	50 °C
OTD	65 °C	3 S	60 °C
MOS OT	100 °C	3 S	75 °C
OTINT	85 °C	3 S	60 °C
UTC	-5 °C	3 S	0 °C

Handshake Send AT

[Clear LOG](#) Auto Scroll 55:47.049 Version:0.01

08:53:28: **Handshake**
 08:55:22: **Data communication failure**
 08:55:28: **Read Calibration Success**
 08:55:29: **Read Calibration Success**
 08:55:41: **Read Threshold Settings Success**
 08:55:47: **Read Threshold Protections Success**

8:55 ... 0.14 KB/s 93%

< 0000136 Wi-Fi

Parallel battery Calibration Threshold **Tool**

Other data

RateFCCRated capacity(mAh)

FCCEffective capacity(mAh)

Full calibration voltage(mV)

Full calibration voltage delay(S)

BMS type

Cycle

SOH

Chg Threshold(0.1A)

Dsg Threshold(0.1A)

Sleep voltage(mV)

Correction value(mV)

Read Write

CalibrationTime

Handshake Send AT

[Clear LOG](#) Auto Scroll 55:54.744 Version:0.01

08:53:28: **Handshake**
 08:55:22: **Data communication failure**
 08:55:28: **Read Calibration Success**
 08:55:29: **Read Calibration Success**
 08:55:41: **Read Threshold Settings Success**
 08:55:47: **Read Threshold Protections Success**
 08:55:54: **Read Other data Success**




14.25 Bluetooth connection mode

A: Click the [TB] Blue Link button

B: Requires GPS and Bluetooth permissions

C: Search and select the corresponding Bluetooth name, then click on connect

D: The display interface is similar to the WI-FI display interface



User Manual

E: Bluetooth connection supports online upgrade of BMS

Network file: Load network upgrade program

Local file: Load the local upgrade program for the phone

